Sarasota Breeze
Outdoor Living Furniture

12' x 12' OVERHANG GAZEBO

ASSEMBLY INSTRUCTIONS

PARTS LIST

A	Gazebo	B	Corner Rib	C	Ground Stake	D	Tie-down Cord
QTY	1	QTY	4	QTY	8	QTY	4

SET UP

STEP 1



Set the gazebo frame in the center of the set-up area. Grasp the legs on one side while a partner grasps the legs on the opposite side. Working at the same time, pull out on the legs to spread the frame open as far as possible.You may need to step backward carefully to allow room to open the frame.

STEP 2



Secure each corner with the valance on the canopy, make sure the vlance to fit well around the top of the leg on the frame.

Sarasota Breeze
Outdoor Living Furniture

STEP 3





Hold the corner with one hand while you grab the side cross bar and slide the locking bracket up with the other hand until the locking pin pops into place. Repeat this process on the remaining corners to open the frame completely. Insert Corner Rib into top corner bracket until the pin pops into place. Pull the fabric corner of canopy to wrap over the rib end,. Repeat this process on the remaining corners, so the overhang is formed.

STEP 4



Tilt and pull the inner leg out to extend the height of the gazebo to the desired level with three options, the latch should click into place at each position, always make sure all 4 legs in the same level.
After the height is fixed, tighten each fabric leg panel by hooking into position holes at the bottom end of each leg. There are three holes, the lowest suits the first height, and the highest suits the third height, then the middle is for the second.

STEP 5



Attach the Tie-down Cord to each corner, and tie the other end with the Ground Stake. Pull the cord tight and hammer the stake into the loop, working one corner at a time, continue to fix the other 4 stakes with the foot plate of legs. Use the stakes to secure the structure, especially in windy conditions.

Sarasota Breeze
Outdoor Living Furniture

STEP 3



Press the button on the locking slider at the corner bracket to disengage the frame and allow it to collapse. Lift the frame off the ground and slowly walk towards partner being careful not to pinch fingers.
Store this gazebo in roller bag provided.

Sarasota Breeze
Outdoor Living Furniture

TAKE DOWN

STEP 1



Remove stakes from the ground, detach hook to disengage the leg fabric panel. Raise the leg off the ground and tilt the leg bottom end, then press snap button to slide back the lower pole. Repeat until all four legs have been lowered.

STEP 2



Remove the fabric corner of canopy.and release the Corner Ribs out of the top corner bracket by snapping the pin.